



de Montageanleitung
en Mounting instruction
fr Instruction de montage
sv Monteringsinstruktion
nl Montage-aanwijzing
it Istruzione di montaggio
fi Asennus ohjeet
es Instrucción de montaje
da Monteringsvejledning

Temperaturfühler
Temperature sensor
Sonde de température
Temperaturgivare
Temperatuuropnemer
Termosonda
Lämpötila-anturi
Sonda de temperatura
Temperaturføler

QAP...
ARG22.2




de Maßbilder
en Dimensions
fr Encombremnts

sv Måttuppgifter
nl Maatschets
it Ingombri


fi Mittapiirros
es Dimensiones
da Målskitse

QAP...



- 1) Wirksame Fühlerlänge
 Active detector length
 Longueur de sonde active
 Effektiv givarlänge
 Werkzame opnemerlengte
 Lunghezza attiva
 Anturin toirniva pituus
 Longitud de sonda activa
 Effektiv følerlængde

ARG22.2



Maße in mm
 Dimensions in mm
 Dimensions en mm
 Mått i mm
 Maten in mm
 Dimensioni in mm
 Mitat mm
 Dimensiones en mm
 Mål i mm